


Horizon Measuring Guide



Horizon Measuring

- All screens are ordered "top of the top track" to the "bottom of the bottom track" - **this is the same height as the housing**
- Take at least 3 measurements and use the smallest one - calculate from there
- The width does not need fractions, round up to the nearest inch
- Housings can be installed on the surface or inside the jamb (the 80mm Horizon cannot be anchored sideways into the jamb, it must be fastened from the front to the back)
- Extra 3 inches of track provided to be cut at site
- Extra mesh to provide some flexibility at time of install
- Clearance is required when under a header

Measure inside the jamb and add, or as detailed on next page



Side can **only** be determined looking at the FRONT OF THE HOUSING

