

## Congratulations on Your Purchase!

Please Register Your Warranty @  
[www.wizardscreens.com/warranty-registration](http://www.wizardscreens.com/warranty-registration)

### WARRANTY

Wizard Screens offers a **limited five year** warranty on all components, excluding screen mesh, to the original purchaser of The Horizon from the date of purchase. This warranty is non-transferable and will remain intact for the original purchaser provided the product was installed by an Authorized Dealer and/or factory trained installer and has not been moved or altered in any way.

Wizard warrants the components shall be free of defects in materials and workmanship. "Defects" are defined in this warranty as imperfections that impair the utility of the retractable screen. Wrinkles in the mesh or puckering along its edges in itself does not constitute a defect.

The limited warranty does not include components that have been damaged by misuse, abuse, unauthorized repair or modification, lack of maintenance, normal weathering, fading, scratching, airborne or applied corrosive contaminants, acts of God or other causes beyond the control of Wizard Screens.

If a component is defective and you require assistance, please contact your original point of purchase. Please retain your invoice as proof of purchase. Proof of purchase is required for any after sale service.



## MAINTENANCE & OPERATION

To ensure your The Horizon functions for years of trouble free use it must be maintained and operated in accordance to these guidelines.

### Use

Screens should be retracted when not in use. This helps maintain the longevity of your screen and keeps screens clean.

### Operation

Always release the Hand Brake System to move the screen. Rotate the brake lever (this releases the brakes) before sliding your screen to desired position.


Allow spring to retract the screen - do not force or push the screen back.

### Lubrication

Use Wizard Dry silicone in the systems mesh slot in the track to ensure the screens move freely.



Lower Track



Top Track

### Cleaning

When cleaning be sure not to use corrosive cleaners, as they may damage the painted finish. Track grooves must be kept clean. Remove dust from grooves using a brush, cloth or vacuum. To clean the mesh we suggest vacuuming it with an upholstery brush, being careful not to snag the screen material.

Do not allow dirt or debris to build up in the tracks, vacuum/clean as necessary.

### Service

If you require service or have any questions please contact the original point of purchase to arrange a service call.

*A View Towards  
Excellence*