

Somfy Remote Quick Programming Guide

Wake up the motor and set the limits **if power is lost before this process is complete the steps will need to be repeated*

- a. Take the remote out of its box and set it to the correct channel if multiple units (remotes come with battery and are ready to use out of the box)
- b. Plug the unit in to the outlet
 - i. Screen will jog up and down
- c. To wake the motor up press the up and down buttons together until the unit jogs up and down
 - i. When the motor jogs the unit is woken up
- d. Ensure the motor is rolling the correct way
 - i. If you press the down button the screen should move down
 - ii. If you press down and the screen rolls up, press and hold the My button until the motor jogs up and down
 - iii. Once the motor jogs press the down button and the screen will roll the correct way
- e. If the screen is wrapped around the tube, press the My and the down buttons together to set that point as the upper limit
 - i. The screen will begin to roll down
 - ii. Hold the middle of the screen material at the zipper and with light pressure helps guide the screen material down
 - i. This is because there is currently no weight on the screen material
- f. Once the screen gets to about 1' from the lowest point press the My button to stop the screen
- g. Press the My button and the up button together to set the bottom limit
 - i. The screen will begin to roll up
- h. Press the My button to stop the screen then immediately press hold the My button until the screen jogs
- i. Within 10 seconds of stopping the screen press and hold the program button on the back of the remote until the motor jogs twice
- j. This motor is now programmed and can be unplugged if necessary
- k. Limits should be adjusted once the installation of the unit is complete

**Once screen is programmed the My button can be pressed to stop a screen in motion at any point*

Adjusting the Limits

1. To adjust the upper limit
 - a. Press the up button on the remote to send the screen up to the upper limit
 - b. Press and hold the up and down buttons on the remote until the screen jogs up and down
 - c. Press the up or down buttons on the remote to adjust where the upper limit should be
 - d. Once the correct limit is reached press and hold the My button on the remote until the screen jogs up and down
 - e. The new upper limit is set

2. To adjust the lower limit
 - a. Press the down button on the remote to send the screen up to the lower limit
 - b. Press and hold the up and down buttons on the remote until the screen jogs up and down
 - c. Press the up or down buttons on the remote to adjust where the lower limit should be
 - d. Once the correct limit is reached press and hold the My button on the remote until the screen jogs up and down
 - e. The new lower limit is set

Full Power Reset

1. Unplug the power cord for the motor for 2 seconds
2. Plug the power cord back in for 10 seconds
3. Unplug the power cord for 2 seconds
4. Plug the power cord back in and the screen should either jog, or start moving in either direction for 5 seconds
5. Press the My button to stop the screen if necessary when moving
6. Press and hold the program button on the back of the remote until the motor jogs TWICE
7. The motor should now be in factory reset mode and will need to be woken up again

**If you press the up or down button and the screen moves at all then you will have to do the process over again*